

# Instructions for installation

## Monolith 6,9 kW

### Wave Control unit

Affixing the sensor to the ceiling:  
distance from heater frame 100–300 mm

The temperature sensor should be installed no less than 1000 mm from an undirected air vent income, or less than 500 mm from a directed air vent.

